



CD RDS RECEIVER
RECEPTOR DE CD CON RDS
CD PLAYER CON RDS

DEH-S1150UB

Quick start guide
Guía de inicio rápido
Guía de Inicio Rapido

QRD3654-A

This guide is intended to guide you through the basic functions of this unit. For details, please refer to the Operation manual stored on the website. <http://www.pioneer-latin.com/en/support/operating-manual/>

Before You Start

Thank you for purchasing this PIONEER product. To ensure proper use, please read this guide before using this product. It is especially important that you read and observe **WARNINGS** and **CAUTIONS** in this guide. Please keep the guide in a safe and accessible place for future reference.

WARNING
Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without training and experience in electronic equipment and automotive accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards if you do not attempt to operate the unit while driving. Make sure to pull off the road and park your vehicle in a safe location before attempting to use the controls on the device.

CAUTION:
USE OF CONTROL OR ADJUSTMENT OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.
THE USE OF OPTICAL INSTRUMENTS WITH THIS PRODUCT WILL INCREASE EYE HAZARD.

CAUTION
Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
Always keep the volume low enough to hear outside sounds.
This product is evaluated in a normal climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60965.

CAUTION
This product is a class 1 laser product classified under the Safety of laser products, IEC 60825-1:2007.

CLASS 1 LASER PRODUCT

If you experience problems
Should this unit fail to work properly, please contact your dealer or nearest authorized PIONEER Service Station.


About the main menu

You can adjust various settings in the main menu.

- Press the **M.C.** dial to display the main menu.
- Turn the **M.C.** dial to select one of the categories below, then press to confirm.
 - FUNCTION settings
 - AUDIO settings
 - SYSTEM settings
 - ILLUMINATION settings
 - MIXTRAX settings
- Turn the **M.C.** dial to select the options, then press to confirm.

Basic operation

DEH-S1150UB



- FUNCTION settings
- AUDIO settings
- SYSTEM settings
- ILLUMINATION settings
- MIXTRAX settings

ADVERTENCIA
No trate de instalar o reparar este producto usted mismo. La instalación o la reparación de este producto por parte de personas sin cualificación ni experiencia en equipos electrónicos y accesorios para automóviles puede ser peligrosa y puede exponerle al riesgo de sufrir una descarga eléctrica u otros peligros.
No intente utilizar la unidad mientras está conduciendo. Asegúrese de salir de la carretera y aparcar su vehículo en un lugar seguro antes de intentar utilizar los controles del dispositivo.

PRECAUCIÓN
No permita que esta unidad entre en contacto con humedad y/o líquidos. Puede sufrir un choque eléctrico. Además, el contacto con líquidos puede provocar daños en la unidad, humo o sobrecalentamiento.
Mantenga siempre el volumen lo suficientemente bajo como para poder escuchar los sonidos que provienen del exterior.
Este producto es evaluado en condiciones de clima moderado y tropical en aparatos electrónicos de audio, video y similares. Requisitos de seguridad, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico



ADVERTENCIA
No permita que esta unidad entre en contacto con humedad y/o líquidos. Puede sufrir un choque eléctrico. Además, el contacto con líquidos puede provocar daños en la unidad, humo o sobrecalentamiento.
Mantenga siempre el volumen lo suficientemente bajo como para poder escuchar los sonidos que provienen del exterior.
Este producto es evaluado en condiciones de clima moderado y tropical en aparatos electrónicos de audio, video y similares. Requisitos de seguridad, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1


En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico

Conexiones

ADVERTENCIA
Cuando se utiliza la salida de altavoces en 4 canales, use altavoces con una potencia máxima y entre 4 Ω (valor de impedancia). No utilice altavoces de 1 a 3 Ω con esta unidad.
Cuando un subwoofer de 2 Ω utilice la salida de altavoz trasero, use altavoces con una potencia nominal mayor a 70 W.
Consulte las conexiones para ver un método de conexión.
El cable negro es la tierra. Al instalar esta unidad o un amplificador de potencia le vende por separado, asegure de conectar primero el cable a tierra. Asegúrese de que el cable a tierra esté conectado correctamente a las partes metálicas de la carrocería del automóvil. El cable a tierra del amplificador de potencia y el cable a tierra del automóvil (por separado) deben conectarse al automóvil (por separado con tornillos independientes. Si el tornillo del cable a tierra se afloja o cae, podría producir un incendio, lo que provocaría humo o un mal funcionamiento.
Dos dispositivos conectados al automóvil (por separado (cables a tierra) y no se suministra para esta unidad.

Importante
Al instalar esta unidad en un vehículo sin terminal de ACC (accesorio) en la llave de encendido, si no se conecta el cable rojo al terminal que detecta el funcionamiento de la llave de encendido, es posible que se agote la batería.
El símbolo gráfico que se ve en el producto significa corriente continua.
La configuración de las funciones y de audio que no sea la de terminal remota del volante o de las salidas RCA del preamplificador se almacenará en la memoria. Si se desconecta la unidad de la alimentación.



ACERCA DEL MENÚ PRINCIPAL
Puede ajustar distintos valores de configuración en el menú principal.


- Presione el dial **M.C.** para mostrar el menú principal.
- Gire el dial **M.C.** para seleccionar una de las categorías siguientes y presione para confirmar.
 - Ajustes FUNCTION
 - Ajustes AUDIO
 - Ajustes SYSTEM
 - Ajustes ILLUMINATION
 - Ajustes MIXTRAX
- Gire el dial **M.C.** para seleccionar las opciones y presione para confirmar.

Operaciones frecuentes

Objetivo	Funcionamiento
Encender la unidad	Presione SRC/OFF para encender la unidad.
Ajustar el volumen	Mantenga presionado SRC/OFF para apagar la unidad.
Seleccionar un origen	Gire el dial M.C. .
Cambiar la información de visualización	Presione SRC/OFF varias veces.
Volver a la visualización/lista anterior	Presione DISP/DISP OFF varias veces.
Volver a la visualización normal desde el menú	Presione BAND/ .
Cambiar el brillo de la pantalla	Mantenga presionado BAND/ .
Intensificar el nivel de graves	Mantenga presionado BAND/ .
	Presione BASS .
	• Puede seleccionar el nivel de graves (BASS BOOST).

Connections

WARNING
When speaker output is used by 4 channels, use speakers rated over 50 W (maximum input power) and between 4 Ω to 8 Ω (impedance value). Do not use 1 Ω to 3 Ω speakers for this unit.
When rear speaker output is used by a 2 Ω subwoofer, use speakers rated for over 70 W.
Please refer to connections for a connection method.
The black cable is ground. When installing this unit or power amp (sold separately), make sure to connect the ground wire first. Ensure that the ground wire is properly connected to metal parts of the car's body. The ground wire of the power amp and the one of this unit or any other device must be connected to the car separately with different screws. If the screw for the ground wire loosens or falls out, it could result in fire, operation of airbags or malfunction.
Two devices connected to the car separately (ground wires).



Important
When installing this unit in a vehicle without an ACC (accessory) position on the ignition switch, failure to connect the red cable to the terminal that detects operation of the ignition key may result in battery drain.
Use this unit with a 12-volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.
To prevent a short-circuit, overheating or malfunction, be sure to follow the directions below:
Disconnect the negative terminal of the battery

Frequently used operations

Purpose	Operation
Turn on the power	Press SRC/OFF to turn on the power.
Adjust the volume	Press and hold SRC/OFF to turn off the power.
Select a source	Press SRC/OFF repeatedly.
Change the display information	Press DISP/DISP OFF repeatedly.
Return to the previous display/list	Press and hold DISP/DISP OFF to turn off the display information.
Return to the normal display from the menu	Press BAND/ .
Change the display brightness	Press and hold BAND/ .
Boost the bass level	Press BASS . • You can select the bass level in (BASS BOOST).


CAUTION
Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
Always keep the volume low enough to hear outside sounds.
This product is evaluated in a normal climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico



ADVERTENCIA
No permita que esta unidad entre en contacto con humedad y/o líquidos. Puede sufrir un choque eléctrico. Además, el contacto con líquidos puede provocar daños en la unidad, humo o sobrecalentamiento.
Mantenga siempre el volumen lo suficientemente bajo como para poder escuchar los sonidos que provienen del exterior.
Este producto es evaluado en condiciones de clima moderado y tropical en aparatos electrónicos de audio, video y similares. Requisitos de seguridad, IEC 60965.



PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico

This unit



Important
In the case of ⑩ above, two 4 Ω subwoofers wired in parallel will represent a 2 Ω load.
To power cord input
① Left
② Right
③ Front speaker
④ Rear speaker
⑤ White
⑥ White/black
⑦ Gray
⑧ Gray/black
⑨ Green
⑩ Green/black
⑪ Violet
⑫ Violet/black

Setup operation

- Press the **M.C.** dial.
 - Turn the **M.C.** dial to select the options, then press to confirm. To proceed to the next menu option, you need to confirm your selection.
- | Menu Item | Description |
|---|--|
| LANGUAGE
[ENG](English), [ESP](Spanish) | Select the language to display the text information from a compressed audio file. |
| CLOCK SET | Set the clock.
1 Turn the M.C. dial to adjust the hour, then press to confirm.
The indicator moves to the minute setting automatically.
2 Turn the M.C. dial to adjust the minute, then press to confirm. |
| FM STEP
[100], [50] | Select the FM tuning step from 100 kHz or 50 kHz. |
| AM STEP
[10], [9] | Select the AM tuning step from 10 kHz or 9 kHz. |

QUIT: YES appears when all the settings have been made. To return to the first item of the setup menu, turn the **M.C.** dial to select (**QUIT: NO**), then press to confirm.

Press the **M.C.** dial to confirm the settings.

CAUTION
Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
Always keep the volume low enough to hear outside sounds.
This product is evaluated in a normal climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico

Funcionamiento de la configuración



Operaciones frecuentes

Funcionamiento de la configuración

Funcionamiento de la configuración

Funcionamiento de la configuración

Power cord



Important
In the case of ⑩ above, two 4 Ω subwoofers wired in parallel will represent a 2 Ω load.
To power cord input
① Left
② Right
③ Front speaker
④ Rear speaker
⑤ White
⑥ White/black
⑦ Gray
⑧ Gray/black
⑨ Green
⑩ Green/black
⑪ Violet
⑫ Violet/black

Tuner operation

- Press **SRC/OFF** to select [RADIO].
- Press **BAND/** to select the band. [FM1] ◀▶ [FM2] ◀▶ [FM3] ◀▶ [AM]
- Press a number button (1/Λ to 6/↵).

Best stations memory (BSM)
1 After selecting the band, press the **M.C.** dial to display the main menu.
2 Turn the **M.C.** dial to select [FUNCTION], then press to confirm.
3 Turn the **M.C.** dial to select [BSM], then press to confirm.

To store stations manually
1 While receiving the station you want to store, press and hold one of the number buttons (1/Λ to 6/↵) until it stops flashing.

CAUTION
Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
Always keep the volume low enough to hear outside sounds.
This product is evaluated in a normal climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico

Funcionamiento de la configuración



Operaciones frecuentes

Funcionamiento de la configuración

Funcionamiento de la configuración

Funcionamiento de la configuración


Power amp (sold separately)



Important
In the case of ⑩ above, two 4 Ω subwoofers wired in parallel will represent a 2 Ω load.
To power cord input
① Left
② Right
③ Front speaker
④ Rear speaker
⑤ White
⑥ White/black
⑦ Gray
⑧ Gray/black
⑨ Green
⑩ Green/black
⑪ Violet
⑫ Violet/black

Installation

- Check all connections and systems before final installation. Do not use unauthorized parts as this may cause malfunctions.
Consult your dealer if installation requires drilling of holes or other modification to the vehicle. Do not install this unit where:
- It may interfere with operation of the vehicle.
- It may cause injury to a passenger as a result of a sudden stop.
- Install this unit away from hot places such as near the heater outlet.
Optimum performance is obtained when the unit is installed at an angle of less than 60°.
When installing, to ensure proper heat dissipation when using this unit, make sure you leave ample space behind the rear panel and wrap any loose cables so they are not blocking the vents.
- Leave ample space.



CAUTION
Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
Always keep the volume low enough to hear outside sounds.
This product is evaluated in a normal climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico

Funcionamiento de la configuración

Operaciones frecuentes

Funcionamiento de la configuración


Funcionamiento de la configuración

Funcionamiento de la configuración

Funcionamiento de la configuración

DIN mount installation

- Insert the supplied mounting sleeve into the dashboard.
- Secure the mounting sleeve by using a screwdriver to bend the metal tabs (90°) into place.



When not using the supplied mounting sleeve
1 Determine the appropriate position where the holes on the bracket and the side of the unit match.
2 Tighten the screws on each side.
① Truss screw (5 mm x 9 mm)
② Mounting bracket
③ Dashboard or console

Making a connection with Pioneer ARC APP

Pioneer's Advanced app converts your compatible smartphone into a powerful touchscreen remote control.

Download Now
Pioneer ARC

WARNING
Do not attempt to operate the application while driving. Make sure to pull off the road and park your vehicle in a safe location before attempting to use the controls on the application.

- Enter the SYSTEM menu (refer to "About the main menu").
- Turn the **M.C.** dial to select [ANDROID WIRED], then press to confirm.
- Turn the **M.C.** dial to select [APP CONTROL], then press to confirm.
- Turn the **M.C.** dial to select [PAPP AUTO ON], then press to confirm.
- Turn the **M.C.** dial to select [ON], then press to confirm.
- Connect this unit with the Android device via USB. Pioneer ARC APP on the device starts automatically.

CAUTION
Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
Always keep the volume low enough to hear outside sounds.
This product is evaluated in a normal climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico

Funcionamiento de la configuración

Operaciones frecuentes

Funcionamiento de la configuración

Funcionamiento de la configuración

Funcionamiento de la configuración

Funcionamiento de la configuración

Funcionamiento de la configuración

Removing the unit (installed with the supplied mounting sleeve)

- Remove the trim ring.
① Trim ring
② Notched tab
- Releasing the trim ring allows easier access to the trim ring.
- When attaching the trim ring, point the side with the notched tab down.
- Insert the supplied extraction keys into both sides of the unit until they click into place.
- Pull the unit out of the dashboard.



When not using the supplied mounting sleeve
1 Determine the appropriate position where the holes on the bracket and the side of the unit match.
2 Tighten the screws on each side.
① Truss screw (5 mm x 9 mm)
② Mounting bracket
③ Dashboard or console

Making a connection with Pioneer ARC APP

Pioneer's Advanced app converts your compatible smartphone into a powerful touchscreen remote control.

Download Now
Pioneer ARC

WARNING
Do not attempt to operate the application while driving. Make sure to pull off the road and park your vehicle in a safe location before attempting to use the controls on the application.

- Enter the SYSTEM menu (refer to "About the main menu").
- Turn the **M.C.** dial to select [ANDROID WIRED], then press to confirm.
- Turn the **M.C.** dial to select [APP CONTROL], then press to confirm.
- Turn the **M.C.** dial to select [PAPP AUTO ON], then press to confirm.
- Turn the **M.C.** dial to select [ON], then press to confirm.
- Connect this unit with the Android device via USB. Pioneer ARC APP on the device starts automatically.

CAUTION
Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
Always keep the volume low enough to hear outside sounds.
This product is evaluated in a normal climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60965.

PRECAUCIÓN
Este producto es un producto de láser de clase 1, clasificado como tal en Seguridad de productos de láser, IEC 60825-1:2007.

PRODUCTO LASER CLASE 1

En caso de problemas con el dispositivo
Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Funcionamiento básico

Funcionamiento de la configuración

Operaciones frecuentes

Funcionamiento de la configuración

Funcionamiento de la configuración

Funcionamiento de la configuración

